

Roof Spoiler Painting and Installation Manual

Included in the package






- --> Roof Spoiler
- --> Silicone

⚠ We highly recommend having your products painted and installed by a specialist.

Stage one: Painting

Sanding





Paint the entire surface of the product with 3-in-1 primer at room temperature (20°- 25°C).

Priming

* DRYING TIME (at least 3 hours)



The first priming step will reveal any grazes or spots left on the product's surface. Apply polyester filler (putty) to these.



Leave Ventilation Holes at the bottom side of the product Open.

2nd Sanding

Repeat the sanding step as indicated above.

2nd Priming

Repeat the priming step as indicated above.

Final Sanding

Sand the whole surface of the product with a **600 grit** sandpaper.



Clean thoroughly the product and paint it with the final acrylic paint according to the car's paint code.

A Painting temperature should not exceed 40° C.

Final Painting



Stage two: Installation



Pencil - Tape Measure - Masking Tape - Cloth

Resources needed!



At least two people



Around 30 min

Centering



Measure and center the spoiler on the car. Then, draw a pencil outline on the surface of the car around the product's edges.

The distance between the roof spoiler's edge and a reference point on your car (i.e., rear lights) should be equal for each side.

Cleaning



Clean the car's surface and the spoiler with cleaner. Let the surfaces dry.

Apply silicone (included in the package) over the product's surface that attaches to the car*. Then, re-center the spoiler on the car following the drawn outline from the previous step.

Attaching



* Do not apply silicone to Ventilation Holes at the bottom side of the product.

Securing



Press down and secure the roof spoiler with suitable strong adhesive tape.

The adhesive tape should hold the product on the car tightly.

Vehicle Use



The vehicle is now ready to be used according to the instructions below.



max.

24 h





